



DIGITSOLE®

FOOTWEAR. REINVENTED.



# WARM SERIES V.6

FAQ

# CONTENT

<b>FAQ</b>	<b>1</b>
<b>BEFORE BUYING</b>	<b>3</b>
WHAT SHOES WILL I BE ABLE TO PUT INSOLE IN ?.....	3
WHAT SIZES ARE AVAILABLE ?.....	3
WHAT SIZE OF WARM SERIES SHOULD I BUY ?.....	3
HOW SHOULD I TRIM MY INSOLES ?.....	3
IS THE PRODUCT A SINGLE SOLE OR IS IT A PAIR OF SOLES ?.....	3
WHAT SMARTPHONE IS COMPATIBLE TO CONNECT TO MY INSOLES ?.....	3
<b>PRODUCT DESCRIPTION</b>	<b>4</b>
HOW CAN MY WARM SERIES KEEP MY FEET WARM ?.....	4
DOES IT HEAT MY WHOLE FOOT ?.....	4
HOW LONG DOES IT TAKE TO REACH THE DESIRED TEMPERATURE ?.....	4
WHAT IS THE BATTERY LIFE OF THE INSOLES ?.....	4
WHAT IS THE BATTERY LIFE OF THE INSOLES ?.....	4
WHAT IS in the box ?.....	4
WHAT CHARGER CAN I USE ?.....	4
HOW LONG DOES IT TAKE TO CHARGE MY INSOLES ?.....	5
DO I NEED TO WAIT UNTIL MY INSOLES ARE FULLY DISCHARGED TO CHARGE THEM ?.....	5
CAN THE BATTERIES BE REPLACED ?.....	5
HOW MANY CHARGING CYCLES CAN THE INSOLES WITHSTAND ?.....	5
IS THERE A RISK OF OVERCHARGING IF I LEAVE THE INSOLES PLUGGED IN FOR THE NIGHT ?.....	5
for which kind of users ?.....	5
<b>COMFORT AND SAFETY</b>	<b>5</b>
WHAT IS THE COMFORT TEMPERATURE FOR MY FEET ?.....	5
IS THIS PRODUCT SAFE ?.....	6
I HAVE BLOOD CIRCULATION ISSUES. CAN I USE THE WARM SERIES ?.....	6
CAN THE SOLES REPLACE ORTHOPEDIC INSOLES ?.....	6
CAN YOU PLACE ORTHOPEDIC INSOLES AND WARM SERIES ON TOP OF EACH OTHER ?.....	6
<b>USING THE PRODUCT</b>	<b>7</b>
how do i download the app ?.....	7
i can't turn on my insoles. what shall i do ?.....	8
i can't turn on my insoles off. what shall i do ?.....	8
WHAT WILL HAPPEN IF MY PHONE BATTERY DISCHARGED OR MY PHONE IS OUT OF RANGE OF MY INSOLES ?.....	8
THE LED ON MY INSOLE IS BLINKING, WHAT DOES THIS MEAN ?.....	9
MY PHONE DOESN'T SEEM TO DETECT MY INSOLES. WHAT SOULD I DO ?.....	9
WHEN I TOUCH THE HEATED INSOLE, I DON'T FEEL THAT IT'S AS WARM AS THE SMARTPHONE SAYS. IS MY PRODUCT STILL WORKING FINE ?.....	9
HOW CAN I CLEAN MY INSOLES ?.....	9



## BEFORE BUYING

### WHAT SHOES WILL I BE ABLE TO PUT INSOLE IN ?

The Warm Series will fit into most shoes, including sneakers, boots and ankle boots, sports shoes, hiking shoes, snowboarding boots and ski boots, motorcycle boots, safety shoes... It is particularly suited to shoes with removable insoles. The insoles will however not fit in most fashion shoes.

### WHAT SIZES ARE AVAILABLE ?

Available sizes range from EUR 36 to 47 to US Men's 4 to 13 / Women's 5.5 to 10. Please refer to the size chart below:

SIZES			
EUR	US MEN	US WOMEN	UK
36-37	4-5	6-6,5	3,5-4
38-39	6-7	7,5-8,5	4,5-6
40-41	7,5-8	9-10	6,5-7,5
42-43	8,5-9,5	10,5-11	8-9
44-45	10-11		9,5-10,5
46-47	12-13		11-12

### WHAT SIZE OF WARM SERIES SHOULD I BUY ?

You should buy the model corresponding to your actual shoes size. Each model is designed to fit two sizes of shoes. You can trim your insoles to adjust to your actual foot size. For instance, if you are a European 38, you should buy the EUR 38/39 and trim it to fit your shoes.

If you are located in a country where we have retail distribution, you can always visit one of our retailers as they have fitting samples of all sizes.

### HOW SHOULD I TRIM MY INSOLES ?

You can cut your insoles using scissors but you need to be careful not to cut beyond the limit line drawn on the underside the insole. Cutting beyond the line will damage the heat-pad leading to the insoles not working anymore. Cutting beyond the line will also void the warranty.

### IS THE PRODUCT A SINGLE SOLE OR IS IT A PAIR OF SOLES ?

The WARM SERIES is sold in pairs.

### WHAT SMARTPHONE IS COMPATIBLE TO CONNECT TO MY INSOLES ?

To be able to connect your Digitsole insoles to your smartphone, your device must feature Bluetooth Smart, and operating with Android 5.0 minimum or iOS 9 and above. You can find this information in your device settings.

## PRODUCT DESCRIPTION

---

### HOW CAN MY WARM SERIES KEEP MY FEET WARM ?

We have been able to insert electronics into the insoles, including a rechargeable battery and a heat-pad. Basically the heat-pad transforms energy from the battery into heat. This is managed by the user via the application.

For your safety and comfort. A built in thermostat will regulate the temperature of the insoles so that it is maintained and never exceeds the temperature set-up.

---

### DOES IT HEAT MY WHOLE FOOT ?

The heating area is located at the front of the insoles. In most cases, the sensation starts at the extremities - you rarely feel the cold at the heel - this is why we have chosen to heat the front. Thanks to the thermostat, the heating is auto-regulated, which means that the temperature chosen is set in the entire shoe environment. The thermostat make the insoles smart because they adapt the temperature to their environment for more comfort and well-being.

---

### HOW LONG DOES IT TAKE TO REACH THE DESIRED TEMPERATURE ?

It takes one to three minutes to reach the desired temperature. The body temperature and the type of shoe and socks being worn depend on the ambient temperature.

---

### WHAT IS THE BATTERY LIFE OF THE INSOLES ?

The battery will last from 2 to 6 hours. However, battery life will depend on usage conditions like the temperature you set, the external temperature, the body temperature the type of shoes and socks being worn.

---

### WHAT IS THE BATTERY LIFE OF THE INSOLES ?

The battery will last from 2 to 6 hours. However, battery life will depend on usage conditions like the temperature you set, the external temperature, the body temperature the type of shoes and socks being worn.

---

### WHAT IS IN THE BOX ?

In the box, you will find your pair of Warm Series insoles, a double micro-USB cable and a user guide.

---

### WHAT CHARGER CAN I USE ?

We recommend to use USB chargers with outputs between 1A and 2A. Chargers delivering less than 1A will not charge the insoles properly. We recommend that only our double micro-USB cable is used.

---

## HOW LONG DOES IT TAKE TO CHARGE MY INSOLES ?

Depending on the type and output of USB charger you will use, your insoles can be recharged in as little as 2 hour 30 minutes with the fast charging technology we have built in (users chargers delivering 2A output)

---

## DO I NEED TO WAIT UNTIL MY INSOLES ARE FULLY DISCHARGED TO CHARGE THEM ?

No. Charging the insoles even while not fully discharged will not damage them.

---

## CAN THE BATTERIES BE REPLACED ?

No.

---

## HOW MANY CHARGING CYCLES CAN THE INSOLES WITHSTAND ?

The insoles should withstand a minimum of 500 cycles.

---

## IS THERE A RISK OF OVERCHARGING IF I LEAVE THE INSOLES PLUGGED IN FOR THE NIGHT ?

No, there is no risk of over-charging, as the battery will stop charging when it is completely recharged. However, avoid leaving the insoles plugged unnecessarily. When you don't use your insoles for a long period, make sure they're fully charged before used.

---

## FOR WHICH KIND OF USERS ?

**Heating feature** – recommended for all weather conditions, for anyone suffering from cold feet, but also to improve comfort and health.

**Leisure** – Hiking, Fishing, Hunting, Cycling, etc...

**Professional** – Construction sites & warehouse workers, Army, Police, etc...

**Health** - Many people with blood circulation issues will find that the Warm Series will improve their well-being, for instance those with Raynaud's syndrome. The Warm Series is not a medical device. People should seek proper advice in case of doubt.

**Performance tracking** - keep track of how many steps you make anywhere, anytime. The Warm Series and its dedicated app also provide information that can be used to evaluate your well-being.

---

## COMFORT AND SAFETY

---

### WHAT IS THE COMFORT TEMPERATURE FOR MY FEET ?

Most people will feel comfortable with a temperature of 30°C / 86°F to 35°C. However the perception of temperature and comfort can vary significantly from person to person. For your

comfort, you can set the temperature of your insoles by one degree increments ranging between 20°C / 68°F and 45°C/113°F.

Note that excessive temperature can cause discomfort.

---

## IS THIS PRODUCT SAFE ?

Here at Digitsole, we do not compromise the safety of our customers. During the designing of the Warm Series, we strove to keep safety as a highest priority and worked on making the product water-resistant and extremely robust.

### **Water-resistant:**

The electronics and battery are sealed in a water-resistant case that is certified IP56. This means that unlike any other product, it will not only withstand the moisture and humidity of your feet, but it will also withstand any accidental water penetration in your shoes. Digitsole is the only company on the market today with a safe, fully water-resistant heated insole. Should water be in contact with the insoles, let them dry at ambient temperature. Do not place them on a hot surface or a radiator.

### **Shock resistant:**

When you walk, your body weight up to 3 times if force is applied by your feet with each step. This is why we have designed the insoles to support up to 500 kg / 1100 lbs.

### **Dust resistant:**

Norm IP56: resistant to dust

---

## I HAVE BLOOD CIRCULATION ISSUES. CAN I USE THE WARM SERIES ?

In many cases, it is poor blood circulation in the tips of the toe that leads to the sensation of cold. Hence, heating the extremities will facilitate blood circulation and in turn reduce the sensation of cold. This can apply to people who are occasionally cold to people with certain identified diseases like Raynaud's syndrome. In these cases, the Warm Series will definitely improve your comfort.

However, please note that the Warm Series is not a medical device. Should you have any concern as to whether you can use our product in your specific condition, please seek proper medical advice.

---

## CAN THE SOLES REPLACE ORTHOPEDIC INSOLES ?

No, as they are made in standardized shapes and sizes, they cannot replace orthopedic soles.

---

## CAN YOU PLACE ORTHOPEDIC INSOLES AND WARM SERIES ON TOP OF EACH OTHER ?

No. There is a risk of excessive compression of your foot inside your shoe if you place the two pairs of insoles on top of each other. Further, you will not feel the heat of your insoles.

## USING THE PRODUCT

### HOW DO I DOWNLOAD THE APP ?

To download the app, you need a smartphone that is compatible with the app, i.e., a phone running Android 5.0 and above or iOS 9 and above. When you visit your phone's app store, search for the dedicated app, known as "Digitsole WARM SERIES" and take the one with the white insole on the icon. Therefore, download the app.

#### ***Help to pair your insoles :***

##### *First Step: APP DOWNLOAD*

Download your App from Google Play (Android) and Apple Store (IOS).

In the search bar type in "Digitsole Warm Series" and follow the steps for downloading the App.

##### *Second Step: CONGRATULATIONS*

Once the App has been successfully downloaded click open and you will see the page congratulating you. Then, click on the CONTINUE bar at the bottom of the page.

##### *Third Step: REGISTERING*

You will be asked to provide your email address for validation of you purchase, and notifications regarding new updates.

When done click "CONTINUE".

##### *Fourth Step: CHECK THE STARTUP REQUIREMENTS*

You have to verify the following requirements in order to successfully pair your new insoles to the device. If you don't do so, you won't be able to use them.

- Your insoles need to be unplugged
- Your insoles need to be OFF (Check that the LED lights on the interior side of the insoles, near to the micro USD plug are neither Green, nor Red)

Once this is checked, tap on "I AM READY" on the bottom button.

##### *Fifth Step: PERSONAL INFORMATION*

We need some basic information about yourself, so that we can provide you with the best possible results with our Smart Tracking System.

Enter you Name, Gender by clicking on each field and entering your information using either the keyboard or the sliding bar.

When done click on "CONNECT MY INSOLES" at the bottom of the page.

### Sixth Step: DIGITSOLE PAIRING PROCESS

You should now see "RIGHT INSOLE CONNECTED" and "LEFT INSOLE CONNECTED" at the bottom of each insole image.

### Just in case: help me, it is not working!!!

Don't worry, you will succeed in a few seconds.

- When ready, click on the "TRY AGAIN" button, and wait for 5 seconds.

- If one of your insoles is still not pairing with your phone, make sure that the red LED is on and flash. If not, it probably means that your insole is fully discharged. Plug it in to a power source, and wait for at least 10mn before trying the pairing process again. You won't have enough battery to fully use it, but you will at least be able to pair it.

If your insole is still not pairing after this quick charge, please contact us so that we can help you at <https://www.digitsole.com/contact-us/>

Now that the pairing is done, you are now ready to warm your feet and track your day.

---

### I CAN'T TURN ON MY INSOLES. WHAT SHALL I DO ?

First, make sure your insoles are fully charged:

- Connect a micro-USB cable to each insole and
- Connect the USB end to a USB power source (computer or USB charger)
- A red LED should turn on each insole to indicate charging
- The red LEDs will turn off once the insoles are fully charged and still plugged in.

If after following these steps you still can't turn your insoles on, please contact us: <https://www.digitsole.com/contact-us/>

---

### I CAN'T TURN ON MY INSOLES OFF. WHAT SHALL I DO ?

The two ways to turn off your insoles are to stop the heater on your application or you can also wait 20 minutes of inactivity, they will turn off automatically.

If after following these steps you still can't turn your insoles on, please contact us: <https://www.digitsole.com/contact-us/>

---

### WHAT WILL HAPPEN IF MY PHONE BATTERY DISCHARGED OR MY PHONE IS OUT OF RANGE OF MY INSOLES ?

In the case your phone battery discharges, you will no longer be able to interact with your insoles. However, should you have set a temperature before the battery has discharged, the temperature will still be regulated at the last set temperature. Additionally, if you started a tracking session, the



insoles will continue to collect and store data. Once you reconnect your phone, you will be able to regain control over your insoles, both for heating and tracking data.

In case your phone battery has discharged and you want to turn off your insoles, the insoles turn off automatically after 20 minutes of inactivity.

---

#### THE LED ON MY INSOLE IS BLINKING, WHAT DOES THIS MEAN ?

If the LED is blinking, it means that your insole is fully charged.

---

#### MY PHONE DOESN'T SEEM TO DETECT MY INSOLES. WHAT SHOULD I DO ?

- Check that your Bluetooth is on
- Fully charge your insoles: Plug your insoles, until the red LED is turn off. The red Led is turn off when the battery is full.
- Make sure to unplug your insoles, insoles cannot be detected while charging - Turn your phone's bluetooth off and on again
- If still encountering issues, reset the insoles by plugging them in/out.

If you still can't detect your insoles, please contact us: <https://www.digitsole.com/contact-us/>

---

#### WHEN I TOUCH THE HEATED INSOLE, I DON'T FEEL THAT IT'S AS WARM AS THE SMARTPHONE SAYS. IS MY PRODUCT STILL WORKING FINE ?

Yes. Your Warm Series were designed to maintain the desired temperature while enclosed in your shoes, not in open air. Their purpose is to maintain your feet at a comfortable temperature in cold weather, while also avoiding them becoming hot and sweaty.

Also note that the sensation of hot or cold is different for each individual and is not perceived in the same way in your hand or feet.

---

#### HOW CAN I CLEAN MY INSOLES ?

You can clean your insoles using a damp cloth with soap and let them dry at ambient temperature. Do not place them on a hot surface or a radiator. Cleaning your insoles with a damp cloth will not damage your insoles as they are IP56 water-resistant. Do not use other cleaning products.

