



DIGITSOLE®

FOOTWEAR. REINVENTED.



WARM SERIES V.6

USER MANUAL





CONTENT

USER MANUAL	1
GET STARTED	3
CONTENT OF THE WARM SERIES BOX	3
SETTINGS	3
PREPARATION OF INSOLES	3
CONFIGURE THE WARM SERIES ON YOUR SMARTPHONE	3
CREATE A WARM SERIES ACCOUNT	4
YOUR WARM SERIES	5
BATTERY AND RECHARGE	5
THE BATTERY LEVEL	6
CLEANING	6
HEATING	6
TRACKING	6
CONFIGURATION AND SETTINGS	6
UPDATE YOUR INSOLES	7
COMPLIANCE STATEMENT	7





GET STARTED

Enjoy the first connected heated insoles for outdoor activities. They will help you to keep your feet warm and keep up with your activity.

CONTENT OF THE WARM SERIES BOX

In the box you will find:

- 2 Warm Series V.6 insoles
- 1 User manual
- 1 Cable (1 USB – 2 Micro-USB)



CONFIGURATION

The Warm Series are the first intelligent heated insoles that follow your daily activities. We recommend using the dedicated Warm Series application available on iOS and Android.

When creating your Warm Series account, the application will ask you for personal information (height, weight,...) in order to analyze your activity with precision (distance, calories burned...)

CONFIGURE THE INSOLES

Upon receipt of your insoles:

1. Charge your soles for 2.5 hours.
2. Adjust the size of your insoles by cutting on the marked line if necessary, and adapt them to your shoes.

CONFIGURE THE WARM SERIES ON YOUR SMARTPHONE

The Warm Series application is free and compatible with iOS (from iOS 9.0) and Android (from Android 5.0).


1. You can find the Warm Series application by typing "Warm Series" in the search bar (Warm Series for V5 and Warm Series V6 for V6):
 - On App Store for iOS
 - On Play Store for Android
2. Install the application
3. Enable Bluetooth on your smartphone
4. Launch the application
5. Create your account on the application



CREATE A WARM SERIES ACCOUNT


If you do not have an account, you must create it using Facebook, Twitter or your email address.

If you want to use the email address, choose a password and confirm.




CUSTOMIZE YOUR WARM SERIES ACCOUNT

1. Enter your first name
2. Choose your profile photo
3. Enter your:
 - ✓ High,
 - ✓ Weight,
 - ✓ ...



CONNECT YOUR INSOLES TO YOUR SMARTPHONE

The QR Code is located on the back of your insoles (or in the user manual).
All you need to do is scan it to connect your insoles to your smartphone.





YOUR WARM SERIES

BATTERY AND RECHARGE

To charge your insoles:

1. Connect the charging cable to the USB port on your computer or to a USB power supply unit. We recommend using a power supply unit (of minimum current 2.0A).
2. Then connect your insoles to the 2 micro USB

A full charge takes 2.5 hours. Once charged, the insoles can last up to 8 hours. The battery's lifespan varies depending on the use.



BATTERY LEVEL

If the battery is low, the battery icon will turn red. You have to recharge them.

CLEANING

Clean your Warm Series regularly. We recommend the use of wet wipes without chemicals. Never wash your insoles in the washer.





HEATING


When your 2 insoles are connected, you can set the temperature from 20 to 45°C for each sole.



TRACKING

You can track your activity by going to "Tracker". When you start your activity, you will visualize the distance, burned calories and steps.

After your activity you can review your previous activity by selecting "History". This table contains all your activities.




CONFIGURATION AND SETTINGS

To access the app settings, tap the icon.

You can change several parameters:

- Unit of measurement
- Celsius or fahrenheit unit
- Weight unit
- Activate the Eco mode





UPDATE YOUR INSOLES

We regularly improve our products to provide you with the best experience. You can receive a notification to update the application or your firmware. We recommend that you keep your insoles up to date.

The update may take a few minutes. We recommend that you fully recharge your insoles before updating them.

COMPLIANCE STATEMENT

You can find the compliance statement for USA (FCC), Canada (IC) and the European Union (EU) at: <https://www.digitsole.com/safety-instructions>